



Simple to Start:





1. Press the ON Key.
2. A series of start-up screens will appear.
3. The Standard Display appears showing setpoint and box temperature when the unit is running.

4. The Standard Display defaults to the "Temperature Watch" screen after 2 1/2 minutes. This screen displays same setpoint and box temperature in larger font.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Set: CYCLE-SENTRY or Continuous Run







1. Return to the Standard Display.
2. Press the MODE SELECTION Key.
3. The "Programming Continuous Mode" or "Programming CYCLE-SENTRY Mode" screen briefly appears.
4. The "New System Mode is Continuous" screen or the "New System Mode CYCLE-SENTRY" screen briefly appears.

5. The Standard Display appears and the heading on top of screen reads the new mode.

6. Pressing the MODE SELECTION Key again will change the unit back to the previous mode.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.



Simple to Set: Setpoint Temperature



1. Return to the Standard Display.
2. Press the SETPOINT Key on the Standard Display.
3. Press the + or - Keys to change the setpoint reading.
4. Press the YES or NO key accordingly.
5. The Standard Display appears with setpoint changed to the new setpoint.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.




Simple to Check: Gauges



1. Return to the Standard Display.
2. Press the GAUGES Key.
3. Press BACK or NEXT Keys to scroll through following gauges: Coolant Temperature, Coolant Level, Engine Oil, Pressure, Amps, Battery Voltage, Engine RPM, Discharge Pressure, Suction Pressure, ETV Position, I/O. If no keys are pressed within 30 seconds, the screen will return to the Standard Display.
4. Press the LOCK Key to display any gauge screen for an indefinite period. Press the key again to unlock the screen.
5. Press the EXIT Key to return to the Standard Display.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.



Simple to Defrost: Initiate Manual Defrost



1. Return to the Standard Display.
2. Press the DEFROST Key.
3. Miscellaneous defrost programming screens appear.
4. A modified Standard Display screen appears. The bar indicator will fill in showing the time remaining to complete the Defrost cycle. When the Defrost cycle is complete the display returns to Standard Display screen.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.




Simple to Access: Sensors



1. Return to the Standard Display.
2. Press the SENSORS Key.
3. Press the BACK or NEXT Keys to scroll through the following sensor screens: Control Return Air Temperature, Display Return Air Temperature, Control Discharge Air Temperature, Evaporator Coil Temperature, Ambient Air Temperature, Spare 1 Temperature, Datalogger Temperature, Sensors 1-6 and the Board Temperature Sensor. If no keys are pressed within 30 seconds, the screen will return to the Standard Display.
4. Press the LOCK Key to display any sensor screen for an indefinite period. Press the key again to unlock the screen.
5. Press the EXIT Key to return to the Standard Display.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Check: Pretrip Test





1. Clear all alarm codes.
2. Return to the Standard Display.
3. Press the MENU key.
4. Press the NEXT Key as required to show the Pretrip Menu.
5. Press the SELECT Key to start a Pretrip Test.
6. If the unit is not running, a Full Pretrip will be initiated. If the unit is running in either diesel or electric mode, a Running Pretrip will be performed.

7. When all tests are complete, the results are reported as PASS, CHECK or FAIL. If the results are CHECK or FAIL, the accompanying alarm codes will direct the technician to the cause of the problem.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Check: Hourmeters







1. Return to the Standard Display screen.
2. Press the MENU Key.
3. Scroll through Main Menu by repeatedly pressing the NEXT and BACK Keys until the hourmeters Main Menu Screen appears.

4. Press the SELECT Key to enter the Hourmeters Menu.

5. Press the NEXT and BACK Keys to view the Hourmeter Displays.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to View: Cause of Alarm




1. Return to the Standard Display Screen.
2. Press the MENU Key.
3. Press the NEXT Key until the Alarm Menu appears.
4. Press the SELECT Key. The Alarm Display will appear.
5. If no alarms are present, Alarm 00 is shown.
6. Press the EXIT Key to return to the Standard Display.
7. If alarms are present, the quantity of alarms and the most recent alarm code number will be shown.
8. If there is more than one alarm, press the NEXT Key to view each alarm.

9. If a serious alarm occurs, the unit will be shut down to prevent damage to the unit or the load. If this occurs, the display will show that the unit is shut down and display the alarm code that caused the shutdown.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to View: Clearing Alarm Codes



1. Press the CLEAR Key to clear an alarm.
2. The display screen will return to the Standard Display when the alarms are cleared.
3. Press the HELP key for additional information regarding the alarm shown on the display. Also see the complete Alarm Code list in the next column.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Determine: Cause of Alarm

0. No Alarms Exist
1. Evaporator Coil Sensor
2. Control Return Air Sensor
3. Control Discharge Air Sensor
4. Ambient Air Sensor
5. Coolant Temperature Sensor
6. Engine RPM Sensor
7. High Evaporator Temperature
8. High Discharge Pressure
9. Unit Controlling on Alternate Sensor
10. Sensor Shutdown
11. Sensor Check
12. Glow Plug Check/Intake Air Heater
13. Engine Failed to Crank
14. High Engine Coolant Temperature
15. Low Engine Oil Pressure
16. Engine Failed to Start
17. Cooling Cycle Check
18. Heating Cycle Check
19. Cooling Cycle Fault
20. Heating Cycle Fault
21. Alternator Check
22. Refrigeration Capacity Check
23. Motor RPM High
24. Pre-Trip Abort
25. Defrost Damper Circuit
26. Defrost Damper Stuck Closed
27. Oil Pressure Switch
28. Refrigeration Capacity Low
29. Check Engine RPM
30. Run Relay Circuit
31. Electric Motor Failed to Run
32. Engine Coolant Level
33. Electric Phase Reversed
34. Water Valve Circuit
35. High Speed Circuit
36. Check Engine Coolant Temperature
37. Unit Forced to Low Speed
38. Unit Forced to Low Speed Modulation
39. Check Fuel System
40. Hot Gas Bypass or Hot Gas Bypass Circuit
41. Check Air Flow
42. Check Belts or Clutch
43. Reset Clock
44. Heat Circuit
45. Economizer Valve Circuit
46. Test Mode Time-Out
47. Check Engine Speeds
48. Low Battery Voltage Check
49. Ammeter Out of Calibration Range
50. Engine Stopped - Reason Unknown
51. Pretrip Reminder
52. Low Engine Oil Level
53. Liquid Line Solenoid
54. Hourmeters Failure
55. Maintenance Hourmeter 4 Exceeds Set Time Limit
56. Maintenance Hourmeter 5 Exceeds Set Time Limit
57. Maintenance Hourmeter 6 Exceeds Set Time Limit
58. Controller Reset to Defaults
59. Internal Fault Codes
60. Internal Fault Codes
61. Internal Fault Codes
62. Internal Fault Codes
63. Internal Fault Codes
64. Internal Fault Codes
65. Internal Fault Codes
66. Internal Fault Codes
67. Internal Fault Codes
68. Internal Fault Codes
69. Internal Fault Codes
70. Internal Fault Codes
71. Internal Fault Codes
72. Internal Fault Codes
73. Internal Fault Codes
74. Internal Fault Codes
75. Internal Fault Codes
76. Internal Fault Codes
77. Internal Fault Codes
78. Internal Fault Codes
79. Data Log Overflow
80. Compressor Temperature Sensor
81. High Compressor Temperature
82. High Compressor Temperature Shutdown
83. Low Coolant Temperature
84. Restart Null
85. Forced Unit Operation
86. Discharge Pressure Sensor
87. Suction Pressure Transducer
88. Electronic Throttling Valve Circuit
89. Electric Overload
90. Electric Ready Input
91. Sensor Grades Not Set
92. Low Compressor Suction
93. Loader #1
94. Loader #2
95. Low Fuel Level
96. Fuel Level Sensor
97. High Compressor Pressure Ratio
98. Door Open Time-Out
99. High Discharge Pressure
100. Unit Configuration
101. Auto Switch to Electric
102. Auto Switch to Diesel
103. Liquid Injection Circuit
104. Diesel/Electric Relay Circuit
105. Setpoint Not Entered
106. Engine Run Time Maintenance Reminder #1
107. Engine Run Time Maintenance Reminder #2
108. Electric Run Time Maintenance Reminder #1
109. Electric Run Time Maintenance Reminder #2
110. Total Unit Run Time Maintenance Reminder #1
111. Total Unit Run Time Maintenance Reminder #2
112. Power On Hours
113. Spare Digital Inputs
114. Spare Digital Outputs
115. Display Return Air Sensor
116. Display Discharge Air Sensor

SR-2 Smart Reefer 2 Microprocessor



Driver Guide to Simple Operation

